



**Volvo S40**  
(2001-2002)



**Wiring Diagrams and Electric Model year 2002**

Abbreviations .....	3
How to use the wiring diagram .....	4

## Electrical distribution

Overview .....	6
----------------	---

## Fuses

Engine compartment 11A/1-7 .....	8
Engine compartment 11A/8-10 .....	9
Engine compartment 11A/11-15 .....	10
Engine compartment 11A/17-22 .....	11
Engine compartment 11A/23-31 .....	12
Passenger compartment 11B/7-10 .....	14
Passenger compartment 11B/11-14 .....	15

## Relays

Engine compartment 1-9, misc. ....	16
Passenger compartment 1-7, misc. ....	17

## Distribution rails

15/1 - 15/2 .....	18
15/3 - 15/4 .....	19
15/5 - 15/6 .....	20
15/7 - 15/8 .....	21
Ignition switch .....	22

## Ground connection

31/1 - 31/4 .....	23
31/5 - 31/9 .....	24
31/10 - 31/15 .....	25

## Control modules

Overview .....	26
----------------	----

## Group 23

Engine management system, EMS 2000 .....	28
Engine management system, EMS 2000 Turbo .....	30
Engine management system, Bifuel .....	32
Engine management system, Melco 2 .....	34
Engine management system, Diesel .....	36

## Group 26

Electric cooling fan/AC compressor, EMS 2000 .....	38
Electric cooling fan/AC compressor, Melco 2 .....	39
Electric cooling fan/AC compressor, Diesel .....	40

## Group 27

Cruise control, EMS 2000 .....	41
Cruise control, Melco 2 .....	42
Cruise control, Diesel .....	43

## Group 32, 33

Charging circuit, Starting circuit .....	44
--	----

## Group 35

High and low beams, Fog lights .....	45
Parking lights/side marker lights and license plate lighting .....	46
Reversing and brake lights, filament monitor .....	47
Interior lighting, power sunroof and key-inserted reminder .....	48

## Group 36

Beam length adjustment .....	50
Instrument and control lighting .....	51
Indicators and warning lights .....	52
Wipers/washers, windscreen, headlights and rear window .....	53
12V outlet and horn .....	54
Electronic immobilizer .....	55

## Group 37

Diagnostics system .....	56
--------------------------	----

## Group 38

Seat belt reminder .....	57
Combined instrument panel .....	58

## Group 39

Radio .....	59
-------------	----

## Group 43, 52

Automatic transmission/Vacuum pump EMS 2000 .....	60
---	----

## Group 59

ABS, DSA .....	61
----------------	----

## Group 83, 36

Central locking and anti-theft alarm EU/OS .....	62
Central locking and anti-theft alarm USA .....	64

## Group 83, 84

Power windows and power door mirrors .....	65
--	----

## Group 84

Electrically heated rear window and electrically heated door mirrors .....	66
---	----

## Group 85

Heated seats .....	67
Power seats .....	68

**Order number TP 3959032**  
Replaces previous manual TP 3959031

# Contents

## Group 87

Climate control system .....	69
------------------------------	----

## Group 88

Supplemental Restraint System (SRS).....	70
Towing bracket wiring.....	71

## Connectors

44/1 EMS 2000 .....	72
44/1 MELCO 2 .....	73
44/1 DIESEL.....	74
44/1 BIFUEL .....	75
44/2 MELCO 2 .....	76
44/3 - 44/4.....	77
44/5 - 44/6.....	78
44/7 - 44/8.....	79
44/9 .....	80
44/10 .....	81
44/11 - 44/12.....	82
44/13 .....	83
44/14 - 44/16.....	84
44/17 - 44/19.....	85
44/20 - 44/22.....	86
44/22 - 44/23.....	87
44/24 - 44/25.....	88
44/26 - 44/28.....	89
44/31 - 44/33.....	90
44/34 - 44/37.....	91
44/38 - 44/40.....	92

## Junction points

43/300 - 43/308.....	93
43/309 - 43/318.....	94
43/319 - 43/328.....	95
43/329 - 43/338.....	96
43/339 - 43/348.....	97
43/349 - 43/359.....	98
43/360 - 43/369.....	99
43/370 - 43/379.....	100
43/380 - 43/384.....	101
43/385 - 43/400.....	102
43/401 - 43/410.....	103
43/411 - 43/422.....	104
43/423 - 43/432.....	105
43/433 - 43/601.....	106
43/602 - 43/611.....	107
43/612 - 43/621.....	108

## Cable harness routing in vehicle

Passenger compartment harness - Dashboard harness.....	109
Engine and engine compartment harness EMS 2000 - Passenger compartment harness.....	110
Engine and engine compartment harness Melco 2 - Passenger compartment harness.....	111
Engine and engine compartment harness Diesel - Passenger compartment harness.....	112
Engine compartment harness EMS 2000 .....	113
Engine compartment harness Bifuel .....	114
Engine compartment harness Diesel.....	115
Engine compartment harness Melco 2.....	116
Front door harness, Rear door harness.....	117
Roof harness .....	118
Rear harness, Cargo compartment harness S40 .....	119
Tailgate harness, Rear harness V40 .....	120


## Component illustrations

1/1 - 2/21 .....	121
2/23 - 2/50 .....	122
3/1 - 3/12.....	123
3/13 - 3/24 .....	124
3/25 - 3/51.....	125
3/53 - 4/6.....	126
4/9 - 4/33.....	127
4/35 - 6/1 .....	128
6/2 - 6/14.....	129
6/15 - 6/45 .....	130
6/46 - 7/7.....	131
7/9 - 7/26.....	132
7/26 - 7/47 .....	133
7/49 - 7/56 .....	134
7/58 - 7/72 .....	135
7/73 - 8/2.....	136
8/3 - 8/24.....	137
8/25 - 8/42 .....	138
8/43 - 10/4 .....	139
10/13 - 10/41 .....	140
10/42 - 11/1 .....	141
11/2 - 15/8 .....	142
16/1 - 31/3 .....	143
31/4 - 31/15.....	144
44/1 - 44/13.....	145
44/14 - 44/27 .....	146
44/28 - 44/40 .....	147


## List of components



# Electrical distribution Overview



# Engine management system, Melco 2



# Cable harness routing in vehicle Passenger compartment harness - Dashboard harness

