



Volvo V60 (2011-2012)



Wiring Diagrams and Electric Model Year 2012



VOLVO S60 (11-), V60

WIRING DIAGRAM 2012



TP 39214202

Table of Contents 1:3

Vehicles with SRS (Airbag)/SIPS bag/IC (Inflatable curtain)	2
Explanations	6
Abbreviations	6
How to use the wiring diagrams 1:2	7
Overview without Start/stop function	9
Overview with Start/stop function	10
Overview, Distribution box in engine compartment	11
Overview, Distribution box in passenger compartment	12
Overview, Distribution box in cargo compartment	13

Fuses

Distribution box in engine compartment F1 - F7	14
Distribution box in engine compartment F8 - F23	15
Distribution box in engine compartment F27 - F36	16
Distribution box in engine compartment F37 - F38	17
Distribution box in engine compartment F39 - F44	18
Central Electronic Module (CEM) F1 - F8	19
Central Electronic Module (CEM) F9 - F19	20
Central Electronic Module (CEM) F20 - F24	21
Distribution box in passenger compartment F1 - F17 ...	22
Distribution box in passenger compartment F18 - F30	23
Distribution box in engine compartment, cold zone	24
Distribution box in cargo compartment FA1 - FA11	25
Battery PF1-PF2	26

Relays

Relays in the engine compartment	27
Relays in the engine compartment and passenger compartment	28
Relays in cargo compartment	29

Ground connections

Overview	30
31/1 - 31/7	31
31/10 - 31/15 continues	32
31/15 - 31/68	33
31/83 - 31/89	34
31/90 - 31/XX4	35
31/XX10 - 31/TRM	36

Control modules

Overview locations	37
Overview designations	38
Central Electronic Module (CEM) 1:3	39
Data communication, High speed CAN	42
Data communication intermediate speed CAN, LHD ...	43
Data communication intermediate speed CAN, RHD ..	44
Data communication Local CAN	45
Data communication, LIN 1:2	46
Data communication MOST	48
Steering Wheel Module (SWM)	49

Group 26 Cooling system

Cooling fan 4-Cyl. Turbo 1.6l & 2.0l	50
Cooling fan 4-Cyl. Diesel DV6C	51
Cooling fan, 5-Cyl. Diesel	52
Cooling fan, 5-Cyl. Turbo & 6-Cyl.	53

Group 27 Engine controls

Cruise control 4-Cyl. Turbo 1.6l	54
Cruise control 4-Cyl. Turbo 2.0l	55
Cruise control 4-Cyl. Diesel DV6C	56
Cruise control 5-Cyl. Diesel	57
Cruise control 5-Cyl. Turbo & 6-Cyl.	58
Start-/Stop function 4-Cyl. 1.6l Turbo	59
Start-/Stop function 4-Cyl. 1.6l Diesel DV6C	60
Start-/Stop function 5-Cyl. Diesel	61

Group 28 Ignition and control system

Engine management system 4-Cyl. 1.6l Turbo 1:2	62
Engine management system 4-Cyl. 2.0l Turbo 1:2	64
Engine management system, 5-Cyl. Turbo 1:2	66
Engine management system, 6-Cyl. Turbo 1:2	68
Engine management system, 4-Cyl. Diesel DV6C 1:3	70
Engine management system, 5-Cyl. Diesel 1:3	73
Emission control 4-Cyl. Turbo 1.6l	76
Emission control 4-Cyl. Turbo 2.0l	77
Emission control 5-Cyl. Turbo	78
Emission control 6-Cyl.	79

Table of Contents 2:3

Group 32 Alternator and voltage regulator

Power supply 4-Cyl. without Start/Stop	80
Power supply 4-Cyl. with Start/Stop	81
Power supply 5-Cyl. & 6-Cyl. without Start/Stop.....	82
Power supply 5-Cyl. Diesel with Start/Stop	83

Group 33 Starting system

Starting system 4-Cyl.....	84
Starting system, 5-Cyl. & 6-Cyl.....	85

Group 35 Lighting

High and low beam	86
High and low beam (Dual Xenon).....	87
Beam length adjustment, manual	88
Running/Parking light, Tail lights S60.....	89
Running/Parking light, Tail lights V60.....	90
Running/Parking light, Tail lights (Dual Xenon) S60....	91
Running/Parking light, Tail lights (Dual Xenon) V60....	92
Fog lights S60.....	93
Fog lights V60.....	94
Brake lights S60.....	95
Brake lights V60.....	96
Reversing lights S60.....	97
Reversing lights V60.....	98
Follow-me-home lighting LHD	99
Follow-me-home lighting RHD	100
Interior lighting, LHD 1:2.....	101
Interior lighting, RHD 1:2	103
Active headlight	105
Lighting in door sill trims	106
Auxiliary lights.....	107

Group 36 Additional electrical equipment

Rain sensor.....	108
Direction indicator and hazard warning flashers LHD S60	109
Direction indicator and hazard warning flashers LHD V60	110
Direction indicator and hazard warning flashers RHD S60	111
Direction indicator and hazard warning flashers RHD V60	112
Wiper/washer windshield.....	113
Washer headlights.....	114
Wiper/Washer rear windowV60	115
Horn.....	116
Keyless vehicle 1:2.....	117
Anti-theft alarm	119
Parking assistance.....	120
Collision warning with power brake booster	121
Tire pressure monitoring system (TPMS).....	122
Alcohol lock.....	123

Group 37 Wiring and fuses

Diagnostics system	124
Outlet 12V.....	125
12 V outlet, V60	126
Cable harness towbar/tow hitch 13-pin S60	127
Cable harness towbar/tow hitch 13-pin V60	128

Group 38 Instruments

Seat belt reminder	129
Driver information module.....	130

Group 39 Other

Audio Premium 1:3	131
Audio 1:2.....	134
Cellular phone 1:2.....	136
DAB Radio	138
Rear seat entertainment, RSE.....	139
Multimedia monitor with DVD, Dual Screen (RSE)....	140
TV receiver / TV control module S60	141
TV receiver / TV control module V60	142
Bluetooth Handsfree	143
Navigation system and Traffic information, portable	144
Satellite radio	145
Parking camera front.....	146
Parking camera rear	147
Parking camera rear	148
Parking camera wide angle front	149

Group 43 Transmission

Transmission M66 & MMT 6	150
Automatic transmission, TF-80SC AWD.....	151
Automatic transmission MPS6.....	152
Differential Electronic Module (DEM).....	153

Group 55 Parking brake

Electric parking brake	154
------------------------------	-----

Group 59 Brake system

Brake control system & DSTC	155
-----------------------------------	-----

Group 64 Steering

Speed dependent power steering.....	156
-------------------------------------	-----

Group 76 Shock absorbers

Four-C.....	157
-------------	-----

Table of Contents 3:3

Group 83 Doors and openings

Central locking front doors LHD.....	158
Central locking front doors RHD	159
Central locking rear doors.....	160
Central locking tailgate S60	161
Central locking tailgate V60	162
Central locking fuel filler flap.....	163
Signal receiver central locking	164
Power windows front doors LHD	165
Power windows front doors RHD.....	166
Power windows rear doors	167
Power sunroof.....	168

Group 84 Exterior decorative elements, etc.

Power door mirrors LHD	169
Power door mirrors RHD	170
Heated door mirrors LHD.....	171
Heated door mirrors RHD	172
Blind spot information system LHD.....	173
Blind spot information system RHD	174
Heated rear window.....	175

Group 85 Interior equipment

Power driver's seat with memory function, LHD	176
Power driver's seat with memory function, RHD	177
Power passenger seat, LHD.....	178
Power passenger seat, RHD	179
Heated front seats with fans	180
Heated front seats without fans	181
Heated rear seat.....	182

Group 87 Climate control system

Climate control system, 4-Cyl. 1:2.....	183
Climate control system 4-Cyl. Diesel 1:2.....	185
Climate control system 5-Cyl. & 6-Cyl. 1:2	187
Climate control system PTC-elements	189
Parking heater, auxiliary heater	190
Parking heater, remote start	191

Group 88 Internal equipment

Rear-view mirror with automatic dimming.....	192
Supplemental restraint system 1:2	193
Remote control opener garage door.....	195
Power folding headrest.....	196

Group 89 Body other

Radiator masking blind	197
------------------------------	-----

Connectors..... 198

Branching points230

Cable harness routing in vehicle

Harness engine 4-Cyl. Turbo.....	245
Harness engine, 6-Cyl. Turbo.....	245
Harness engine, 2.0L Diesel.....	246
Harness engine, 2.4L Diesel.....	246
Engine compartment harness LHD.....	247
Engine compartment harness RHD	248
Harness dashboard, LHD	249
Harness Dashboard, RHD	250
Harness Floor, LHD S60.....	251
Harness Floor, RHD S60	252
Floor Harness, LHD V60.....	253
Harness Floor, RHD V60	254
Harness infotainment, LHD S60	255
Harness infotainment, RHD S60.....	256
Harness infotainment, LHD V60	257
Harness infotainment, RHD V60.....	258
Roof harness, S60	259
Roof harness V60	259
Center console harness.....	260
Tunnel harness	260
Harness front door, left	261
Harness front door, right	261
Harness rear door, left.....	262
Harness rear door, right.....	262
Trunk lid/tailgate harness, S60	263
Trunk lid/tailgate harness, V60	263
Harnesses rear axle.....	264


Component illustrations265

Index 1:2320

List of components 1:6322


Electrical distribution

Overview with Start/stop function



Fuses

Distribution box in engine compartment F27 - F36



15/31 Distribution box in engine compartment


No.	No.	Fuse function	via	A
F27	11B/27	2/17 Relay, horn 2/31 Relay, 15-feed 2/182 Relay, headlight washer motor	- - -	5
F28	11B/28	2/64 Relay auxiliary lights 10/65 Auxiliary light, front right 10/69 Auxiliary light, front left	- 2/64 2/64	20
F29	11B/29	16/10 Horn 1 16/11 Horn 2	2/17 2/17	15
F30	11B/30	2/32 Main relay, engine management system 4/46 Engine Control Module (ECM)	- -	10
F31	11B/31	4/28 Transmission Control Module (TCM)	-	15
F32	11B/32	6/73 Coolant pump 8/3 Electromagnetic clutch, climate control system	- 2/22	15
F33	11B/33	2/22 Relay, climate control system 2/133 Relay vacuum pump, Diesel 4-Cyl.	- -	5
F34	11B/34	6/25 Starter motor	2/35	30
F35	11B/35	4/109 Glow plug control module, 5-Cyl. Diesel 20/3-6 Spark plug with ignition coil, 4-Cyl. Turbo 20/3-7 Spark plug with ignition coil, 5-Cyl. Turbo 20/3-8 Spark plug with ignition coil, 6-Cyl. Turbo 20/16 Capacitor, 6-Cyl. Turbo	- - - - -	10 20
F36	11B/36	4/46 Engine Control Module (ECM), 4-Cyl. & 5-Cyl. Diesel 4/46 Engine control module (ECM), 4-Cyl., 5-Cyl. & 6-Cyl. Turbo	- -	15 10
continues				

Cable harness routing in vehicle Harness engine 4-Cyl. Turbo



105127

Cable harness routing in vehicle Harness engine, 6-Cyl. Turbo



101402_T