



Volvo V60 (2012-2013)



Wiring Diagrams and Electric Model Year 2013



VOLVO S60 (11-), V60

WIRING DIAGRAM 2013



TP 39252202 Structure week 12w20

Table of Contents 1:3

Vehicles with SRS (Airbag)/SIPS bag/IC (Inflatable curtain)	2
Explanations & Abbreviations	6
How to use the wiring diagrams 1:2.....	7
Electrical distribution	9
Overview without Start/stop function	9
Overview with Start/stop function	10
Overview, Distribution box in engine compartment	11
Overview, Distribution box in passenger compartment	12
Overview, Distribution box in cargo compartment	13

Fuses

Distribution box in engine compartment F1 - F7	14
Distribution box in engine compartment F8 - F23	15
Distribution box in engine compartment F27 - F36	16
Distribution box in engine compartment F37 - F38	17
Distribution box in engine compartment F39 - F44	18
Central Electronic Module (CEM) F1 - F8	19
Central Electronic Module (CEM) F9 - F19	20
Central Electronic Module (CEM) F20 - F24	21
Distribution box in passenger compartment F1 - F17 ...	22
Distribution box in passenger compartment F18 - F30 ..	23
Distribution box in engine compartment, cold zone	24
Distribution box in cargo compartment FA1 - FA11	25
Battery PF1 - PF2	26

Relays

Relays in the engine compartment	27
Relays in the engine compartment and passenger compartment.....	28
Relays in cargo compartment	29

Ground connections

Overview	30
31/1 - 31/7	31
31/10 - 31/15 continues	32
31/15 - 31/68	33
31/83 - 31/89	34
31/90 - 31/XX4	35
31/XX10 - 31/TRM	36

Control modules

Overview locations	37
Overview designations	38
Central Electronic Module (CEM) 1:3	39
Data communication, High speed CAN	42
Data communication intermediate speed CAN, LHD ...	43
Data communication intermediate speed CAN, RHD ..	44
Data communication Local CAN	45
Data communication, LIN 1:2	46
Data communication MOST	48
Steering Wheel Module (SWM)	49

Group 26 Cooling system

Cooling fan, 4-Cyl. Turbo	50
Cooling fan, 4-Cyl. Diesel	51
Cooling fan, 5-Cyl. Diesel	52
Cooling fan, 5-Cyl. Turbo & 6-Cyl.	53

Group 27 Engine controls

Cruise control 4-Cyl. Turbo 1.6l	54
Cruise control 4-Cyl. Turbo 2.0l	55
Cruise control 4-Cyl. Diesel	56
Cruise control 5-Cyl. Diesel	57
Cruise control 5-Cyl. Turbo & 6-Cyl.	58
Start-/Stop function 4-Cyl. 1.6l Turbo	59
Start-/Stop function 4-Cyl. 1.6l Diesel DV6C	60
Start-/Stop function 5-Cyl. Diesel VED5	61

Group 28 Ignition and control system

Engine management system 4-Cyl. 1.6l Turbo 1:2	62
Engine management system 4-Cyl. 2.0l Turbo 1:2	64
Engine management system, 5-Cyl. Turbo 1:2	66
Engine management system, 6-Cyl. Turbo 1:2	68
Engine management system, 4-Cyl. Diesel 1:3	70
Engine management system, 5-Cyl. Diesel 1:3	73
Emission control 4-Cyl. 1.6l Turbo	76
Emission control 4-Cyl. 2.0l Turbo	77
Emission control 5-Cyl. Turbo	78
Emission control 6-Cyl.	79

Table of Contents 2:3

Group 32 Alternator and voltage regulator

Power supply 4-Cyl. without Start/Stop	80
Power supply 5-Cyl. & 6-Cyl. without Start/Stop.....	81
Power supply 4-Cyl. & 5-Cyl. with Start/Stop.....	82

Group 33 Starting system

Starting system 4-Cyl.....	83
Starting system, 5-Cyl. & 6-Cyl.....	84

Group 35 Lighting

High and low beam.....	85
High and low beam (Dual Xenon).....	86
Beam length adjustment, manual	87
Running/Parking light, Tail lights S60	88
Running/Parking light, Tail lights V60	89
Fog lights S60.....	90
Fog lights V60.....	91
Brake lights S60.....	92
Brake lights V60.....	93
Reversing lights S60.....	94
Reversing lights V60.....	95
Follow-me-home lighting LHD	96
Follow-me-home lighting RHD	97
Interior lighting, LHD 1:2	98
Interior lighting, RHD 1:2	100
Active headlight	102
Lighting in door sill trims	103
Auxiliary lights.....	104

Group 36 Additional electrical equipment

Rain sensor.....	105
Direction indicator and hazard warning flashers LHD S60	106
Direction indicator and hazard warning flashers LHD V60	107
Direction indicator and hazard warning flashers RHD S60.....	108
Direction indicator and hazard warning flashers RHD V60.....	109
Wiper/washer windshield.....	110
Washer headlights.....	111
Wiper/Washer rear windowV60	112
Horn	113
Keyless vehicle 1:2	114
Anti-theft alarm	116
Parking assistance.....	117

Collision warning with power brake booster.....	118
Tire pressure monitoring system (TPMS)	119
Alcohol lock.....	120

Group 37 Wiring and fuses

Diagnostics system	121
Outlet 12V	122
Outlet 12V, V60	123
12 V outlet, V60	124
Cable harness towbar/tow hitch 13-pin S60	125
Cable harness towbar/tow hitch 13-pin V60	126

Group 38 Instruments

Seat belt reminder	127
Driver information module.....	128

Group 39 Other

Audio Premium 1:3	129
Audio 1:2.....	132
Cellular phone 1:2.....	134
DAB Radio	136
Multimedia monitor with DVD, Dual Screen (RSE)	137
TV receiver / TV control module S60	138
TV receiver / TV control module V60	139
Bluetooth Handsfree	140
Navigation system and Traffic information, portable..	141
Satellite radio	142
Parking camera rear	143
Parking camera rear	144
Parking camera wide angle front	145

Group 43 Transmission

Transmission M66.....	146
Automatic transmission AWF21	147
Automatic transmission MPS6.....	148
Differential Electronic Module (DEM).....	149

Group 55 Parking brake

Electric parking brake	150
------------------------------	-----

Group 59 Brake system

Brake control system & DSTC	151
-----------------------------------	-----

Group 64 Steering

Speed dependent power steering.....	152
-------------------------------------	-----

Table of Contents 3:3

Group 76 Shock absorbers

Four-C	153
--------------	-----

Group 83 Doors and openings

Central locking front doors LHD.....	154
Central locking front doors RHD	155
Central locking rear doors.....	156
Central locking tailgate S60.....	157
Central locking tailgate V60.....	158
Central locking fuel filler flap.....	159
Signal receiver central locking	160
Power windows front doors LHD	161
Power windows front doors RHD.....	162
Power windows rear doors	163
Power sunroof.....	164

Group 84 Exterior decorative elements, etc.

Power door mirrors LHD	165
Power door mirrors RHD	166
Heated door mirrors LHD.....	167
Heated door mirrors RHD	168
Blind spot information system LHD.....	169
Blind spot information system RHD	170
Heated rear window.....	171

Group 85 Interior equipment

Power driver's seat with memory function, LHD	172
Power driver's seat with memory function, RHD	173
Power passenger seat, LHD.....	174
Power passenger seat, RHD	175
Heated front seats with fans	176
Heated front seats without fans	177
Heated rear seat.....	178

Group 87 Climate control system

Climate control system PTC-elements	179
Climate control system, 4-Cyl. 1:2	180
Climate control system 4-Cyl. Diesel 1:2	182
Climate control system 5-Cyl. & 6-Cyl. 1:2	184
Parking heater, auxiliary heater	186
Parking heater, remote start	187

Group 88 Internal equipment

Supplemental restraint system 1:2	188
Rear-view mirror with automatic dimming.....	190
Remote control opener garage door.....	191
Power folding headrest.....	192

Group 89 Body other

Radiator masking blind	193
------------------------------	-----

Connectors..... 194

Branching points229

Cable harness routing in vehicle


Harness engine 4-Cyl. Turbo.....	249
Harness engine, 6-Cyl. Turbo	249
Harness engine, 2.0L Diesel.....	250
Harness engine, 2.4L Diesel.....	250
Engine compartment harness LHD.....	251
Engine compartment harness RHD	252
Harness dashboard, LHD	253
Harness Dashboard, RHD	254
Harness Floor, LHD S60.....	255
Harness Floor, RHD S60	256
Floor Harness, LHD V60.....	257
Harness Floor, RHD V60	258
Harness infotainment, LHD S60	259
Harness infotainment, RHD S60.....	260
Harness infotainment, LHD V60	261
Harness infotainment, RHD V60.....	262
Roof harness, S60	263
Roof harness V60	263
Center console harness.....	264
Tunnel harness	264
Harness front door, left	265
Harness front door, right	265
Harness rear door, left	266
Harness rear door, right.....	266
Trunk lid/tailgate harness, S60	267
Trunk lid/tailgate harness, V60	267
Harnesses rear axle.....	268

Component illustrations269

Index 1:2.....326


List of components 1:6328

Electrical distribution



Fuses

Distribution box in engine compartment F27 - F36



15/31 Distribution box in engine compartment


No.	No.	Fuse function	via	A
F27	11B/27	2/17 Relay, horn 2/31 Relay, 15-feed 2/182 Relay, headlight washer motor	- - -	5
F28	11B/28	2/64 Relay auxiliary lights 10/65 Auxiliary light, front right 10/69 Auxiliary light, front left	- 2/64 2/64	20
F29	11B/29	16/10 Horn 1 16/11 Horn 2	2/17 2/17	15
F30	11B/30	2/32 Main relay, engine management system 4/46 Engine Control Module (ECM)	- 2/32	10
F31	11B/31	4/28 Transmission Control Module (TCM)	-	15
F32	11B/32	6/73 Coolant pump, Start/Stop 8/3 Electromagnetic clutch, climate control system	2/22 2/22	15
F33	11B/33	2/14 Relay, glow plug system 2/22 Relay, climate control system	- -	5
F34	11B/34	6/25 Starter motor	2/35	30
F35	11B/35	4/109 Glow plug control module, 5-Cyl. Diesel 20/3-6 Spark plug with ignition coil, 4-Cyl	- -	10
		20/3-7 Spark plug with ignition coil, 5-Cyl. Turbo 20/3-8 Spark plug with ignition coil, 6-Cyl. Turbo 20/16 Capacitor, 6-Cyl. Turbo	- - -	20
F36	11B/36	4/46 Engine Control Module (ECM), 4-Cyl. & 5-Cyl. Diesel	-	15
		4/46 Engine control module (ECM), 4-Cyl., 5-Cyl. & 6-Cyl. Turbo	-	10
continues				

Cable harness routing in vehicle Harness engine 4-Cyl. Turbo



105127

Cable harness routing in vehicle Harness engine, 6-Cyl. Turbo



101402_T