



Volvo XC70
(2012-2013)



Wiring Diagrams and Electric Model Year 2013



VOLVO V70 (08-), XC70 (08-) & S80 (07-)

WIRING DIAGRAM 2013



TP 39251202 Structure week 12w20

Table of Contents 1:3

Vehicles with SRS (Airbag)/SIPS bag/IC (Inflatable curtain)	2
Explanations	6
How to use the wiring diagrams 1:2.....	7

Electrical distribution

Overview without Start/stop function	9
Overview with Start/stop function	10
Overview, Distribution box in engine compartment	11
Overview, Distribution box in passenger compartment	12
Overview, Distribution box in cargo compartment	13

Fuses

Distribution box in engine compartment F1-F7	14
Distribution box in engine compartment F8-F21	15
Distribution box in engine compartment F22-F31	16
Distribution box in engine compartment F32-F37	17
Distribution box in engine compartment F38	18
Distribution box in engine compartment F38-F39	19
Distribution box in engine compartment F39-F44	20
Central electronic module (CEM) F1-F3	21
Central electronic module (CEM) F4-F14	22
Central electronic module (CEM) F15-F24	23
Passenger compartment.....	24
Distribution box in passenger compartment F1-F17	25
Distribution box in passenger compartment F18-F24	26
Distribution box in passenger compartment F25-F30	27
Distribution box in cargo compartment FA1-FA11	28
Distribution box in engine compartment, cold zone F1-MF2	29
Battery PF1-PF2	30

Relays

Relays in the engine compartment	31
Relays in passenger compartment	32
Relays in cargo compartment	33
Central Electronic Module (CEM)	34

Ground connections

Overview	35
31/1 - 31/6	36
31/7 - 31/10	37
31/15 - 31/47	38
31/48 - 31/68	39
31/83 - 31/88	40
31/89 - 31/107	41
31/131 - 31/TRM	42
31/INFOT - 31/AL	43

Control modules

Overview locations	44
Overview designations	45
Central Electronic Module (CEM) 1:3	46
Data communication high speed CAN	49
Data communication high speed CAN, 4-Cyl.	50
Data communication intermediate speed CAN, LHD ..	51
Data communication intermediate speed CAN, RHD ..	52
Data communication MOST	53
Data communication, LIN 1:2	54
Steering Wheel Module (SWM)	56

Group 26 Cooling system

Cooling fan 4-Cyl. Turbo	57
Cooling fan, 5-Cyl. Turbo & 6-Cyl.	58
Cooling fan, 4-Cyl. Diesel	59
Cooling fan, 5-Cyl. Diesel	60

Group 27 Engine controls

Cruise control 4-Cyl. Turbo	61
Cruise control 4-Cyl. Diesel	62
Cruise control 5-Cyl. & 6-Cyl.	63
Cruise control 5-Cyl. Diesel	64
Start-/Stop function 4-Cyl. 1.6l Turbo	65
Start-/Stop function 4-Cyl. 1.6l Diesel DV6C	66
Start-/Stop function 5-Cyl. Diesel VED5	67

Group 28 Ignition and control system

Engine management system, 4-Cyl. Turbo 1.6l 1:2	68
Engine management system, 4-Cyl. Turbo 2.0l 1:2	70
Engine management system, 5-Cyl. Turbo 1:2	72
Engine management system, 4-Cyl. Diesel DV6C 1:3 ..	74
Engine management system, 5-Cyl. Diesel 1:3	77
Engine management system 6-Cyl. PZEV 1:2	80
Engine management system, 6-Cyl. 1:2	82
Engine management system, 6-Cyl. Turbo 1:2	84
Emission control 4-Cyl. 1.6l Turbo	86
Emission control 4-Cyl. 2.0l Turbo	87
Emission control 5-Cyl. Turbo	88
Emission control 6-Cyl.	89

Group 32 Alternator and voltage regulator

Power supply 4-Cyl. Turbo	90
Power supply 4-Cyl. & 5-Cyl. with start/stop	91
Power supply 5-Cyl. & 6-Cyl.	92

Table of Contents 2:3

Group 33 Starting system

Starting system 4-Cyl. Turbo	93
Starting system 5- & 6-Cyl.	94
Starting system 4-Cyl. Diesel.....	95
Starting system 5-Cyl. Diesel.....	96

Group 35 Lighting

High and low beam.....	97
High and low beam (Dual Xenon).....	98
Beam length adjustment, manual	99
Running/Parking light, Tail lights V70	100
Running/Parking light, Tail lights S80.....	101
Fog/Daytime running lights V70.....	102
Fog/Daytime running lights S80.....	103
Brake lights V70.....	104
Brake lights S80.....	105
Reversing lights V70.....	106
Reversing lights S80.....	107
Follow-me-home lighting LHD	108
Follow-me-home lighting RHD	109
Interior lighting, LHD 1:2	110
Interior lighting, RHD 1:2	112
Active headlight	114
Lighting in door sill trims	115
Auxiliary lights.....	116
Lighting mug holder and floor	117

Group 36 Additional electrical equipment

Rain sensor.....	118
Direction indicator and hazard warning flashers LHD V70	119
Direction indicator and hazard warning flashers LHD S80	120
Direction indicator and hazard warning flashers RHD V70	121
Direction indicator and hazard warning flashers RHD S80	122
Wiper/washer windshield.....	123
High pressure headlight washer	124
Wiper/Washer rear window.....	125
Keyless vehicle 1:2.....	126
Horn	128
Anti-theft alarm	129
Parking assistance.....	130
Collision warning with power brake booster	131
Tire pressure monitoring system (TPMS).....	132
Alcohol lock.....	133

Group 37 Wiring and fuses

Diagnostics system	134
Outlet 12 V	135
Outlet 12 V, S80	136
Cable harness towbar/tow hitch 4-pin V70	137
Cable harness towbar/tow hitch 4-pin S80	138
Cable harness towbar/tow hitch 7-pin V70	139
Cable harness towbar/tow hitch 7-pin S80	140
Cable harness towbar/tow hitch 13-pin V70	141
Cable harness towbar/tow hitch 13-pin S80	142
Accessory USB unit (AUU)	143

Group 38 Instruments

Seat belt reminder	144
Driver information module.....	145
Analog clock	146

Group 39 Other, Accessories

TV	147
Cellular phone 1:2.....	148
Audio 1:2.....	150
Audio Premium 1:3	152
DAB Radio	155
Bluetooth Handsfree	156
Rear seat entertainment	157
Satellite radio	158
Parking camera.....	159
Parking camera wide-angle, front	160
Navigation system, portable.....	161

Group 43 Transmission

Transmission M66.....	162
Automatic transmission MPS6.....	163
Automatic transmission AWF21	164
Differential Electronic Module (DEM).....	165

Group 55 Parking brake

Electric parking brake	166
------------------------------	-----

Group 59 Brake system

Brake control system & DSTC	167
-----------------------------------	-----

Group 64 Steering

Speed dependent power steering.....	168
-------------------------------------	-----

Table of Contents 3:3

Group 76 Shock absorbers

Four-C	169
--------------	-----

Group 83 Doors and openings

Central locking front doors LHD.....	170
Central locking front doors RHD	171
Central locking rear doors.....	172
Central locking trunk lid/tailgate V70	173
Central locking trunk lid/tailgate S80	174
Central locking fuel filler flap.....	175
Signal receiver central locking	176
Power windows front doors LHD	177
Power windows front doors RHD.....	178
Power windows rear doors	179
Power sunroof.....	180

Group 84 Exterior decorative elements, etc.

Power door mirrors LHD	181
Power door mirrors RHD	182
Heated door mirrors LHD.....	183
Heated door mirrors RHD	184
Blind spot information system LHD.....	185
Blind spot information system RHD	186
Heated rear window.....	187

Group 85 Interior equipment

Power driver's seat with memory function, LHD	188
Power driver's seat with memory function, RHD	189
Power passenger seat, LHD.....	190
Power passenger seat, RHD	191
Heated front seats with fans	192
Heated front seats without fans	193
Heated rear seat.....	194
Massage seats.....	195

Group 87 Climate control system

Climate control system, 4-Cyl. Turbo 1:2.....	196
Climate control system 4-Cyl. Diesel 1:2	198
Climate control system 5- & 6-Cyl. 1:2	200
Climate control system PTC-elements	202
Parking heater, auxiliary heater	203
Parking heater, remote start	204
Refrigeration box rear seat	205

Group 88 Internal equipment

Supplemental restraint system 1:2	206
---	-----

Power folding headrest.....	208
Remote control garage opening.....	209
Rear-view mirror with automatic dimming.....	210

Connectors..... 211

Branching points252

Cable harness routing in vehicle

Harness engine 4-Cyl. Turbo.....	272
Engine harness, 5-Cyl. Turbo	272
Engine harness, 6-Cyl.....	273
Harness engine, 6-Cyl. Turbo	273
Harness engine, 2.0l Diesel	274
Harness engine, 2.4l Diesel	274
Engine compartment harness LHD.....	275
Engine compartment harness RHD	276
Harness dashboard, LHD	277
Harness Dashboard, RHD	278
Harness Floor, LHD S80.....	279
Harness Floor, RHD S80	280
Harness Floor, LHD V70	281
Harness Floor, RHD V70	282
Harness infotainment, LHD S80	283
Harness infotainment, RHD S80.....	284
Harness infotainment, LHD V70	285
Harness infotainment, RHD V70.....	286
Roof harness, S80	287
Roof harness, V70	287
Center console harness	288
Tunnel harness	288
Harness front door, left	289
Harness front door, right	289
Harness rear door, left	290
Harness rear door, right.....	290
Trunk lid/tailgate harness, S80	291
Trunk lid/tailgate harness, V70	291
Harnesses rear axle.....	292
Executive harnesses.....	293

Component illustrations294

Index 1:2.....356


List of components 1:7358

Overview with Start/stop function



Fuses

Distribution box in engine compartment F38



15/31 Distribution box in engine compartment


No.	No.	Fuse function		via	A
F38	11B/38	8/18	EVAP valve, 4-Cyl.	-	10
		8/28	Turbocharger control valve, 4-Cyl.	-	
		7/17	Mass air flow sensor MAF, 4-Cyl. Turbo	-	
		8/19	Solenoid, variable valve timing, intake, 4-Cyl. Turbo	-	
		8/81	Solenoid, variable valve timing, exhaust, 4-Cyl. Turbo	-	
		8/159	Bypass valve	-	
		2/14	Relay, glow plug system	-	
		6/73	Coolant pump, Start/Stop, 4-Cyl. Diesel	2/14	
		7/17	Mass air flow sensor MAF, 5-Cyl. Turbo	-	
		7/35	Oil level sensor, 5-Cyl. Turbo	-	
		8/3	Electromagnetic clutch climate control system, 5-Cyl. Turbo	-	
		8/18	EVAP valve, 5-Cyl. Turbo	-	
		8/28	Turbocharger control valve, 5-Cyl. Turbo	-	
		8/81	Solenoid, variable valve timing, exhaust, 5-Cyl. Turbo	-	
		8/117	Solenoid, variable valve timing, intake, 5-Cyl. Turbo	-	
		7/35	Oil level sensor, 5-Cyl. Diesel	-	
		8/3	Electromagnetic clutch, climate control system, 5-Cyl. Diesel	-	
		8/113	Bypass valve, EGR cooling, 5-Cyl. Diesel	-	
		8/164	Electric piston cooling valve	-	
continues					

Cable harness routing in vehicle Harness engine 4-Cyl. Turbo



105127

Cable harness routing in vehicle Engine harness, 5-Cyl. Turbo



G035645