



**Volvo XC70**  
(2013-2014)



Wiring Diagrams and Electric Model Year 2014



VOLVO V70 (08-), XC70 (08-) & S80 (07-)

# WIRING DIAGRAM 2014



TP 39264202 Structure week 13w20

# Table of Contents 1:3

Explanations .....	6
How to use the wiring diagrams 1:2.....	7

## Electrical distribution

Overview without Start/stop function .....	9
Overview with Start/stop function .....	10
Overview, Distribution box in engine compartment .....	11
Overview, Distribution box in passenger compartment .....	12
Overview, Distribution box in cargo compartment .....	13

## Fuses

Distribution box in engine compartment F1-F7 .....	14
Distribution box in engine compartment F8-F21 .....	15
Distribution box in engine compartment F22-F31 .....	16
Distribution box in engine compartment F32-F37 .....	17
Distribution box in engine compartment F38 .....	18
Distribution box in engine compartment F38-F39 .....	19
Distribution box in engine compartment F39-F44 .....	20
Central electronic module (CEM) F1-F3 .....	21
Central electronic module (CEM) F4-F14 .....	22
Central electronic module (CEM) F15-F24 .....	23
Passenger compartment .....	24
Distribution box in passenger compartment F1-F17 .....	25
Distribution box in passenger compartment F18-F24 .....	26
Distribution box in passenger compartment F25-F30 .....	27
Distribution box in cargo compartment FA1-FA11 .....	28
Distribution box in engine compartment, cold zone F1-MF2 .....	29
Battery PF1-PF2 .....	30

## Relays

Relays in the engine compartment .....	31
Relays in the engine compartment .....	32
Relays in passenger compartment .....	33
Relays in cargo compartment .....	34

## Ground connections

Overview .....	35
31/2 - 31/6 .....	36
31/7 - 31/10 .....	37
31/10 - 31/15 .....	38
31/47 - 31/65 .....	39
31/66 - 31/83 .....	40
31/84 - 31/90 .....	41
31/93 - 31/XX4 .....	42
31/XX10 - 31/AL .....	43

## Control modules

Overview locations .....	44
Overview designations .....	45
Central Electronic Module (CEM) 1:3 .....	46
Data communication high speed CAN .....	49
Data communication high speed CAN, 4-Cyl .....	50
Data communication intermediate speed CAN, LHD ..	51
Data communication intermediate speed CAN, RHD ..	52
Data communication MOST .....	53
Data communication, LIN 1:2 .....	54
Steering Wheel Module (SWM) .....	56

## Group 26 Cooling system

Cooling fan, 4-Cyl. Turbo .....	57
Cooling fan, 5-Cyl. Turbo .....	58
Cooling fan, 6-Cyl. ....	59
Cooling fan, 4-Cyl. Diesel .....	60
Cooling fan, 5-Cyl. Diesel .....	61

## Group 27 Engine controls

Cruise control 4-Cyl. 1,6l Turbo .....	62
Cruise control 4-Cyl. 2,0l Turbo .....	63
Cruise control 4-Cyl. Diesel .....	64
Cruise control 5-Cyl. & 6-Cyl. ....	65
Cruise control 5-Cyl. Diesel .....	66
Start-/Stop function 4-Cyl. 1.6l Turbo .....	67
Start-/Stop function 4-Cyl. 1.6l Diesel .....	68
Start-/Stop function 5-Cyl. Diesel .....	69
Start-/Stop function 5-Cyl. Turbo .....	70

## Group 28 Ignition and control system

Engine management system, 4-Cyl. Diesel 1:3 .....	71
Engine management system, 4-Cyl. Turbo 1.6l 1:2 .....	74
Engine management system, 4-Cyl. Turbo 2.0l 1:2 .....	76
Engine management system, 5-Cyl. Turbo 1:2 .....	78
Engine management system, 5-Cyl. Diesel 1:3 .....	80
Engine management system 6-Cyl. PZEV 1:2 .....	83
Engine management system, 6-Cyl. 1:2 .....	85
Engine management system, 6-Cyl. Turbo 1:2 .....	87
Emission control 4-Cyl. 1.6l Turbo .....	89
Emission control 4-Cyl. 2.0l Turbo .....	90
Emission control 5-Cyl. Turbo .....	91
Emission control 6-Cyl. ....	92
Emission control 6-Cyl. Turbo .....	93

## Group 32 Alternator and voltage regulator

Power supply 4-Cyl. Turbo .....	94
Power supply 4-Cyl. & 5-Cyl. with start/stop .....	95
Power supply 5-Cyl. & 6-Cyl. ....	96

# Table of Contents 2:3

## Group 33 Starting system

Starting system 4-Cyl. Turbo .....	97
Starting system 5- & 6-Cyl.....	98
Starting system 4-Cyl. Diesel.....	99
Starting system 5-Cyl. Diesel.....	100

## Group 35 Lighting

High and low beam .....	101
High and low beam (Dual Xenon).....	102
Beam length adjustment, manual .....	103
Running/Parking light, Tail lights V70 .....	104
Running/Parking light, Tail lights S80.....	105
Daytime running lights V70 & XC70 .....	106
Daytime running lights S80.....	107
Brake lights V70.....	108
Brake lights S80.....	109
Reversing lights V70 .....	110
Reversing lights S80 .....	111
Follow-me-home lighting LHD .....	112
Follow-me-home lighting RHD.....	113
Interior lighting, LHD 1:2 .....	114
Interior lighting, RHD 1:2 .....	116
Active headlight .....	118
Lighting in door sill trims .....	119
Auxiliary lights.....	120
Lighting mug holder and floor .....	121

## Group 36 Additional electrical equipment

Rain sensor.....	122
Direction indicator and hazard warning flashers	
LHD V70 .....	123
Direction indicator and hazard warning flashers	
LHD S80 .....	124
Direction indicator and hazard warning flashers	
RHD V70.....	125
Direction indicator and hazard warning flashers	
RHD S80.....	126
Wiper/washer windshield .....	127
High pressure headlight washer .....	128
Wiper/Washer rear window.....	129
Keyless vehicle 1:2 .....	130
Horn .....	132
Anti-theft alarm .....	133
Parking assistance.....	134
Collision warning with power brake booster .....	135
Tire pressure monitoring system (TPMS).....	136
Alcohol lock.....	137

## Group 37 Wiring and fuses

Diagnostics system .....	138
Outlet 12 V .....	139
Outlet 12 V, S80.....	140
Cable harness towbar/tow hitch 4-pin V70 .....	141
Cable harness towbar/tow hitch 4-pin S80 .....	142
Cable harness towbar/tow hitch 7-pin V70 .....	143
Cable harness towbar/tow hitch 7-pin S80 .....	144
Cable harness towbar/tow hitch 13-pin V70 .....	145
Cable harness towbar/tow hitch 13-pin S80 .....	146
Accessory USB unit (AUU) .....	147

## Group 38 Instruments

Seat belt reminder .....	148
Driver information module .....	149
Analog clock.....	150

## Group 39 Other, Accessories

TV .....	151
Cellular phone 1:2 .....	152
Audio 1:2 .....	154
Audio Premium 1:3 .....	156
DAB Radio .....	159
Bluetooth Handsfree .....	160
Rear seat entertainment, V70 .....	161
Satellite radio .....	163
Parking camera .....	164
Parking camera wide-angle, front .....	165
Navigation system, portable .....	166
Sensus Connected Touch.....	167

## Group 43 Transmission

Transmission M66 .....	168
Automatic transmission MPS6 .....	169
Automatic transmission AWF21 .....	170
Differential Electronic Module (DEM).....	171

## Group 55 Parking brake

Electric parking brake .....	172
------------------------------	-----

## Group 59 Brake system

Brake control system & DSTC .....	173
-----------------------------------	-----


## Group 64 Steering

Speed dependent power steering .....	174
--------------------------------------	-----

# Table of Contents 3:3


<b>Group 76 Shock absorbers</b>	
Four-C .....	175
<b>Group 83 Doors and openings</b>	
Central locking front doors LHD.....	176
Central locking front doors RHD .....	177
Central locking rear doors.....	178
Central locking trunk lid/tailgate V70 .....	179
Central locking trunk lid/tailgate S80 .....	180
Central locking fuel filler flap.....	181
Signal receiver central locking .....	182
Power windows front doors LHD .....	183
Power windows front doors RHD .....	184
Power windows rear doors .....	185
Power sunroof.....	186
<b>Group 84 Exterior decorative elements, etc.</b>	
Power door mirrors LHD .....	187
Power door mirrors RHD .....	188
Heated door mirrors LHD.....	189
Heated door mirrors RHD .....	190
Blind spot information system LHD.....	191
Blind spot information system RHD .....	192
Heated windshield LHD .....	193
Heated windshield RHD.....	194
Heated rear window.....	195
<b>Group 85 Interior equipment</b>	
Power driver's seat with memory function, LHD .....	196
Power driver's seat with memory function, RHD .....	197
Power passenger seat, LHD.....	198
Power passenger seat, RHD .....	199
Heated steering wheel.....	200
Heated front seats with fans .....	201
Heated front seats without fans .....	202
Heated rear seat.....	203
Massage seats 1:2.....	204
Massage seats 2:2.....	205
<b>Group 87 Climate control system</b>	
Climate control system, 4-Cyl. Turbo 1:2.....	206
Climate control system 4-Cyl. Diesel 1:2 .....	208
Climate control system 5- & 6-Cyl. 1:2 .....	210
Climate control system PTC-elements .....	212
Parking heater, auxiliary heater .....	213
Parking heater, remote start .....	214
Refrigeration box rear seat .....	215
<b>Group 88 Internal equipment</b>	
Supplemental restraint system 1:2.....	216
Power folding headrest .....	218
Remote control garage opening.....	219
Rear-view mirror with automatic dimming .....	220
<b>Connectors.....</b>	<b>221</b>
<b>Branching points .....</b>	<b>261</b>
<b>Cable harness routing in vehicle</b>	
Engine harness, 4-Cyl. Turbo .....	282
Engine harness, 5-Cyl. Turbo .....	282
Engine harness, 6-Cyl.....	283
Engine harness, 6-Cyl. Turbo .....	283
Engine harness, 2.0l Diesel .....	284
Engine harness, 2.4l Diesel .....	284
Engine compartment harness LHD .....	285
Engine compartment harness RHD .....	286
Dashboard harness, LHD .....	287
Dashboard harness, RHD .....	288
Harness Floor, LHD S80.....	289
Floor harness, RHD S80.....	290
Floor harness, LHD V70 .....	291
Floor harness, RHD V70 .....	292
Infotainment harness, LHD S80 .....	293
Infotainment harness, RHD S80 .....	294
Infotainment harness, LHD V70 .....	295
Infotainment harness, RHD V70 .....	296
Roof harness, S80 .....	297
Roof harness, V70 .....	297
Center console harness .....	298
Tunnel harness .....	298
Front door harness, left.....	299
Front door harness, right.....	299
Rear door harness, left .....	300
Rear door harness, right .....	300
Trunk lid/tailgate harness, S80 .....	301
Trunk lid/tailgate harness, V70 .....	301
Rear axle harness .....	302
Executive harnesses .....	303
<b>Component illustrations .....</b>	<b>304</b>
<b>Index 1:2 .....</b>	<b>364</b>
<b>List of components 1:7 .....</b>	<b>366</b>

## **Electrical distribution Overview with Start/Stop function**



## Fuses

### Distribution box in engine compartment F8-F21



### 15/31 Distribution box in engine compartment

No.	No.	Fuse function	via	A
F8	11B/8	9/7 Heated windshield	2/182	40
F9	11B/9	6/1 Wiper Motor Module (WMM)	-	30
F10	11B/10	4/7 Combustion Preheater Module (CPM) 4/106 Control module, remote parking heater start	-	25
F11	11B/11	4/31 Passenger compartment fan control module 6/28 Motor, passenger compartment fan	-	40
F12	11B/12	9/7 Heated windshield	2/182	40
F13	11B/13	4/16 Brake Control Module (BCM), pump	-	40
F14	11B/14	4/16 Brake Control Module (BCM), valves	-	20
F15	11B/15	2/182 Relay, headlight washer motor	-	20
F16	11B/16	10/1 Lamp housing, front left 10/2 Lamp housing, front right	-	10
F17	11B/17	4/56 Central Electronic Module (CEM) F17-F20 Fuses in the Central Electronic Module (CEM)	-	20
F18	11B/18	4/16 Brake Control Module (BCM)	-	5
F19	11B/19	4/99 Speed dependent power steering control module 6/164 Electrical power steering module (EHPS)	-	5
F20	11B/20	4/28 Transmission Control Module (TCM) 4/28B Transmission Control Module (TCM) MPS6 4/46 Engine Control Module (ECM) 4/9 Supplemental restraint system module (SRS)	-	10
F21	11B/21	9/43 Heated windshield washer nozzle, left 9/44 Heated windshield washer nozzle, right	-	10


continues

## Cable harness routing in vehicle Engine harness, 4-Cyl. Turbo



I05127

## Cable harness routing in vehicle Engine harness, 5-Cyl. Turbo



G035645