



Volvo XC90
(2009-2010)



Wiring Diagrams and Electric Model Year 2010



VOLVO XC90

WIRING DIAGRAM 2010



TP 39151202

Table of Contents 1:3

Vehicles with SRS (Airbag)/SIPS bag/	
IC (Inflatable Curtain).....	2
Explanations	6
Abbreviations	6
How to use the wiring diagrams 1:2.....	7
Electrical distribution 1:2.....	9

Fuses

Engine compartment 11A/1-5.....	11
Engine compartment 11B/1-11.....	12
Engine compartment 11B/12-14.....	13
Engine compartment 11B/15.....	14
Engine compartment 11B/16-21.....	15
Passenger compartment 11C/1-4.....	16
Passenger compartment 11C/5-7.....	17
Passenger compartment 11C/8-10.....	18
Passenger compartment 11C/11-14.....	19
Passenger compartment 11O/1-2.....	20
Cargo compartment 11E/1-7.....	21
Cargo compartment 11L/1.....	22
Cargo compartment 11O/6-12.....	23
Central electronic module (CEM) F1-F11.....	24
Central electronic module (CEM) F15-F34.....	25
Rear electronic module (REM) F1-F7.....	26
Rear electronic module (REM) F8-F28.....	27
Rear electronic module (REM) F29-F38.....	28

Relays

Ignition switch and relays.....	29
Engine compartment FMA1 - FST3.....	30
Cargo compartment.....	31
Other relays	32

Ground connections

Overview.....	33
31/1 - 31/44	34
31/46 - 31/67	35
31/70 - 31/83	36
31/84 - 31/88	37

31/89 - 31/93.....	38
31/94 - 31/102.....	39
31/120 - 31/121.....	40

Control modules

Overview locations.....	41
Overview designations.....	42
Central Electronic Module (CEM) 1:2	43
Rear Electronic Module (REM) 1:2	45
Data communication High speed CAN	47
Data communication Low speed CAN	48
Data communication LIN 1:2.....	49
Data communication MOST.....	51

Group 23 Fuel system

Engine management system, Diesel 1:3	52
Engine management system, 5-Cyl. Turbo 1:2.....	55
Engine management system, 6-Cyl. 1:2	57
Engine management system, 8-Cyl. 1:2	59
Emission control 5-Cyl. Turbo.....	61
Emission control 6-Cyl.	62
Emission control 8-Cyl. s	63

Group 26 Cooling system

Cooling fan 5-Cyl.	64
Cooling fan, Diesel, 6-Cyl. & 8-Cyl.....	65

Group 27 Engine controls

Cruise control 5-Cyl.	66
Cruise control, Diesel, 6-Cyl. & 8-Cyl.....	67

Group 32 Alternator and voltage regulator

Power supply	68
--------------------	----

Group 33 Starting system

Starting system 5-Cyl.....	69
Starting system, Diesel, 6-Cyl. & 8-Cyl.....	70

Table of Contents 2:3

Group 35 Lighting

High and low beam/(Dual-Xenon) & Daytime Running Lights	71
Active headlights (ABL)	72
Fog lights	73
Brake lights	74
Reversing light	75
Follow-me-home lighting.....	76
Running/parking light, tail lights & license plate lighting	77
Interior lighting	78
Beam length adjustment.....	79
Auxiliary lights.....	80

Group 36 Additional electrical equipment

Rain sensor.....	81
Direction indicator and hazard warning flashers.....	82
Wiper/Washer Windshield	83
High pressure headlight washer	84
Wiper/Washer Rear window	85
Horn	86
Immobilizer	87
Anti-theft alarm	88
Parking assistance.....	89
Alcohol lock.....	90
Accessory Electronic Module (AEM) 1:2	91

Group 37 Wiring and fuses

Diagnostics system.....	93
Outlet 12 V	94
Cable harness towbar/tow hitch 4/7 pin.....	95
Cable harness towbar/tow hitch 7 pin.....	96
Cable harness towbar/tow hitch 13 pin.....	97
Accessory USB unit (AUU).....	98

Group 38 Instruments

Seat belt reminder	99
Driver information module 5-Cyl.	100
Driver information module Diesel.....	101
Driver information module 6-Cyl.	102
Driver information module 8-Cyl.	103

Group 39 Other

Audio with external amplifier	104
Audio with internal amplifier	105
Navigation system, portable.....	106
Road Traffic Information (RTI)	107
Satellite radio	108
Rear seat entertainment	109
Rear seat entertainment, accessory	110
Infotainment	111
Rear set entertainment roof mounted	112
Parking camera.....	113
Parking camera & AEM.....	114
Bluetooth handsfree, external amplifier	115
Bluetooth handsfree, internal amplifier	116
Bluetooth handsfree with AEM, internal amplifier, LHD	117
Bluetooth handsfree with AEM, internal amplifier, RHD	118
Bluetooth handsfree with AEM, external amplifier, LHD	119
Bluetooth handsfree with AEM, external amplifier, RHD	120

Group 43 Transmission

Automatic transmission AW51 AWD.....	121
Automatic transmission TF-80SC AWD 8-Cyl.	122
Automatic transmission TF-80SC/TF-80SC AWD 6-Cyl. & Diesel	123
Geartronic AW51 AWD	124
Shift lock AW51 AWD & Manual	125
Differential Electronic Module (DEM).....	126

Table of Contents 3:3

Group 59 Brake system

Brake control system	127
----------------------------	-----

Group 64 Steering

Speed dependent power steering	128
--------------------------------------	-----

Group 83 Doors and openings

Central locking	129
Power windows	130
Power sunroof	131

Group 84 Exterior decorative elements, etc.

Power door mirrors	132
Blind spot information system	133
Heated door mirrors	134
Heated rear window	135

Group 85 Interior equipment

Power driver's seat	136
Power passenger seat	137
Heated seats	138
Massage seats with ventilation	139
Heated seats second row of seats	140

Group 87 Climate control system

Climate control system, 5-Cyl. 1:2	141
Climate control system, Diesel, 6-Cyl. & 8-Cyl. 1:2 ...	143
Climate control system, rear	145
Parking heater, auxiliary heater	146
Parking heater, remote start	147

Relay, electric engine heater	148
-------------------------------------	-----

Group 88 Internal equipment

Remote control garage opening	149
Supplemental restraint system	150

Connectors.....151

Branching points177

Cable harness routine in vehicle

Engine harness Gasoline 5-Cyl.	187
Engine harness Gasoline 6-Cyl.	188
Engine harness 8-Cyl.	188
Diesel engine harness	189
Engine compartment harness LHD	190
Engine compartment harness RHD	191
Harness passenger compartment LHD	192
Harness passenger compartment RHD	193
Cargo compartment harness	194
Roof harness	195
Tailgate harness	195
Harness doors	196
Executive harnesses	197


Component illustrations198

Index 1:2251

List of components 1:7253

Fuses


Engine compartment 11B/1-11




11B Fuses in the engine compartment

No.	Fuse function	via	A
1	4/16 Brake Control Module (BCM)	-	30
2	4/16 Brake Control Module (BCM)	-	30
3	6/104 High pressure headlight washer motor	2/182	35
4	6/35 Fuel pump, auxiliary heater 6/73 Coolant pump, auxiliary heater 9/30 Auxiliary heater	4/7 4/7 4/7	25
5	54/8 Connector, cable harness, auxiliary lights, 30-feed	-	20
6	6/25 Starter motor	2/35	35
7	2/90 Relay, windshield wiper, low/high speed 2/91 Relay, intermittent wiping 6/1 Windshield wiper motor	2/91 - 2/90, 2/91	25
8	4/83 Control module fuel pump 6/33 Fuel pump	4/56 4/56	15
9	4/28 Transmission Control Module (TCM), TF-80SC/TF-80SC AWD	-	15
10	4/46 Engine Control Module (ECM), Diesel 20/3-8 Spark plug and ignition coil, not 8-Cyl. 20/14 Condenser, ignition coils, 8-Cyl. 20/46-53 Spark plug with ignition coil, 8-Cyl.	- - - -	20
11	6/44 Cooling fan, electrics box, engine compartment 7/51 Accelerator pedal sensor 8/3 Electromagnetic clutch, climate control system	- - 2/22	10
continues			

Engine management system, 6-Cyl. 2:2



Cable harness routine in vehicle **Engine harness Gasoline 5-Cyl.**



G040623